



## Excavator Telescopic Arm Telescopic Boom for Excavator Long Reach Arm

Our Product Introduction

for more products please visit us on excavatorlongarm.com

### Basic Information

- Place of Origin: Guangdong Province, China
- Brand Name: Kaiping Zhonghe Machinery Manufacturing Co. Ltd
- Certification: CE, Patents, ISO
- Model Number: Telescopic Excavator 009
- Minimum Order Quantity: 1 set / piece
- Price: USD 199.00-USD8999.00
- Packaging Details: Bubble / Wooden cases
- Delivery Time: 5-25/works
- Payment Terms: T/T, L/C or others as you request
- Supply Ability: 5 sets per week



### Product Specification

- Material: Q355B, Q690D
- Warranty: 6 Months
- Cylinders: High Quality Cylinders
- Digging Depth: 8m 10m 12m 14m
- Suitable Excavators: 6ton 20ton 30ton 40ton 55ton
- Color: White Yellow Blue Red Etc
- High Efficiency: Yes
- Bucket Capacity: 0.5cbm 0.8cbm 1cbm



### More Images



### Product Description

#### Telescopic arm for excavator's Overview:

Telescopic arm for excavator is our hot-sale. Excavator telescopic arm can be installed with one standard bucket, clamshell bucket which are very commonly used in construction projects including caissons, house foundation, deep pits etc. The 12m sliding arm is designed to enhance the capabilities of excavators, particularly the PC350 model. This attachment allows for deep excavation tasks, reaching a maximum digging depth of 12 meters. Engineered for durability and efficiency, it is suitable for various applications, including construction.

#### Package Contents of One set of telescopic arm for excavator:

- 1 x 12m Sliding Arm
- 1 bucket

Our Product

Pins  
High pressure hoses  
Double foot switch

#### Specifications of one set of telescopic arm for excavators:

Model Compatibility: 6ton - 55ton excavators  
Maximum Digging Depth: 6m 8m 10m 12m 14m  
Weight: 200-3000kgs  
Material: High-strength steel for enhanced durability, SHAOGANG Brand Q355B material prolong the service life-span  
Hydraulic Requirements: Compatible with standard hydraulic systems of the excavators

#### Installation Instructions of one set of telescopic arm for excavator:

**Preparation:**  
Ensure the excavator is parked on a stable surface and the engine is turned off.  
Gather all necessary tools, including wrenches and hydraulic connectors.  
**Remove Existing Arm:**  
Disconnect the hydraulic lines from the existing arm.  
Unbolt the existing arm from the excavator's main body.  
**Attach the Sliding Arm:**  
Position the 12m sliding arm in alignment with the excavator's mounting points.  
Securely fasten the arm using the provided mounting hardware.  
Ensure all bolts are tightened to the specified torque (refer to the User Manual for torque specifications).  
**Connect Hydraulic Lines:**  
Attach the hydraulic lines to the sliding arm, ensuring there are no leaks.  
Double-check all connections for security.  
**Test the Installation:**  
Start the excavator and operate the sliding arm to ensure smooth functionality.  
Check for any unusual noises or hydraulic issues.

#### Operating Instructions of one set of sliding arm for excavator:

**Controls:** Familiarize yourself with the controls specific to the sliding arm. Refer to the excavator's operator manual if needed.  
**Maximum Load:** Adhere to the load limits specified for the excavator and the sliding arm to prevent damage.  
**Safety Precautions:**  
Always wear appropriate personal protective equipment (PPE) when operating the excavator.  
Ensure the work area is clear of hazards before beginning operation.

#### Maintenance Guidelines

**Regular Inspections:** Conduct routine inspections for any signs of wear or damage on the sliding arm and hydraulic connections.  
**Lubrication:** Regularly lubricate moving parts as per the maintenance guide.  
**Hydraulic Fluid:** Check hydraulic fluid levels frequently and replace any fluid that appears contaminated.

#### Warranty Information

This product comes with a 6 months warranty against manufacturing defects. For warranty claims or service inquiries, please contact our support team.

#### Contact Information

For further assistance, please reach out to our customer service team:

Zhonghe Machinery is a big Manufacturer of Excavator sliding arm  
Any interest,  
Welcome to contact Aria--sales manager of Zhonghe Machinery.  
Whatsapp: [wa.me/+8613822325403](https://wa.me/+8613822325403)  
Email: [aria@excavatorboomarm.com](mailto:aria@excavatorboomarm.com)  
13822325403@163.com  
Website link: [www.excavatorlongarm.com](http://www.excavatorlongarm.com)

#longreacharmforexcavator #longexcavatorboom #longreachboom #excavator #excavation #longexcavatorboom  
#excavatorarm #longboomexcavator #longreachboomexcavator #longboomexcavatorforsale



Jiangmen Kaiping Zhonghe Machinery Manufacturing Co., Ltd



+86 13822325403



[aria@excavatorboomarm.com](mailto:aria@excavatorboomarm.com)



[excavatorlongarm.com](http://excavatorlongarm.com)

9 Huancui West Road, Cuishanhu New Area, Kaiping City, Guangdong Province, China